



































# Handles | Poignées | Griffe

			
AC	EC	T1G	MC
			
AG	EG	T1G	MG
			
AX	EX	T1X	MX
			
AZ	EZ	T1Z	MZ
			
AK	MK	T1K	
			
AF	EF	ME1F	ME2F
			
MF	S1F	T1F	
			
AY	EY	T1Y	MY
			
AQ	EQ	TQ	MQ